



Custom Toyota Truck Tube Works

•5801 Pleasant Valley Road
•Platteville, WI 53818
•Phone: (608) 348-4880
•Web: <http://4xinnovations.com>
•Email: Adam@4xinnovations.com

05+ Tacoma Rear Shackle Flip Kit

1. First jack the rear of the vehicle up and place jack stands under the frame rails just forward of the front spring hangers. Then lower the truck down onto the jack stands. Make sure the jack stands are set high enough to allow the rear axle to completely drop so that it is hanging from the springs and the tires are not touching the ground.
2. Place the jack under the center of the rear axle and apply a slight amount of pressure to it.
3. Remove the bolt that secures the shackle to the factory hanger and place to the side for later use (Fig 1).



Fig 1

4. Next locate the 4 rivets that hold the factory hanger to the frame. Grind the heads off until they are flush with the hanger surface. Then drill a 3/16" hole directly through the center of the rivet about 3/4 of the way through. This is to weaken the rivet to allow it to be removed. Once the hole



Custom Toyota Truck Tube Works

- 5801 Pleasant Valley Road
- Platteville, WI 53818
- Phone: (608) 348-4880
- Web: <http://4xinnovations.com>
- Email: Adam@4xinnovations.com

is drilled use a punch and hammer to drive the rivet out the back side of the frame. (this step may take some time but it is possible!)

5. Once the factory hanger is removed clean up the frame; we advise to apply some paint to the surfaces to help prevent rust (Fig 2).



Fig 2



Custom Toyota Truck Tube Works

- 5801 Pleasant Valley Road
- Platteville, WI 53818
- Phone: (608) 348-4880
- Web: <http://4xinnovations.com>
- Email: Adam@4xinnovations.com

6. Next using a 1/2" bit, drill through all the mounting holes in the frame, making sure to also drill through the crossmember. Then install one of the included 1" bolts through the rear hole in the bottom of the frame, passing through the crossmember and tighten. This bolt holds the frame and crossmember together. Then drop one of the supplied 1 1/2" bolts through the front hole in the bottom of the frame (Fig 3).



Fig 3



Custom Toyota Truck Tube Works

•5801 Pleasant Valley Road
•Platteville, WI 53818
•Phone: (608) 348-4880
•Web: <http://4xinnovations.com>
•Email: Adam@4xinnovations.com

7. Next you need to remove the shackle from the spring and turn it 180 degrees and remount it to the spring (Fig 4).



(Fig 4)

8. Next slide the new hanger over the bolt you placed through the bottom of the frame, then insert the remaining two 1" bolts through the frame. Hand tighten all nuts first. Then starting with the bottom bolt tighten all bolts securely.



Custom Toyota Truck Tube Works

- 5801 Pleasant Valley Road
- Platteville, WI 53818
- Phone: (608) 348-4880
- Web: <http://4xinnovations.com>
- Email: Adam@4xinnovations.com

9. Then flip the shackle up into place, you may have to raise or lower the jack that is supporting the axle to align the shackle with the hanger. Then re-install the factory bolt through the shackle and tighten (Fig 5).



(Fig 5)

10. Re-check all hardware to ensure that everything is tight!! Then repeat steps on the opposite side.



Custom Toyota Truck Tube Works

- 5801 Pleasant Valley Road
- Platteville, WI 53818
- Phone: (608) 348-4880
- Web: <http://4xinnovations.com>
- Email: Adam@4xinnovations.com

All products sold by 4x Innovations LLC are intended for off road use only. Installation of these products releases 4x Innovations LLC from any liabilities related to the use of these products. Installation of certain parts may void original factory warranties. Products may adversely affect vehicle performance and or handling characteristics. Professional installation is advised; please remember to observe proper safety procedures.

Thank you for your business!